

GENERAL INFORMATION

Traction Control, 4WD & AWD Identification & Disable Procedures - All Models

* PLEASE READ THIS FIRST *

Placing a non-compatible vehicle on a single-axle dynamometer could result in a safety hazard to technicians and damage to vehicle. Vehicles which use All-Wheel Drive (AWD) or traction control may not be clearly marked. Use common sense and take all necessary precautions when placing any vehicle on the dynamometer. Determine between full-time 4WD and All-Wheel Drive (AWD) for testing purposes. The following tables include information related to full-time 4WD and AWD vehicles, and how to disable the traction control system (if disengageable).

WARNING: DO NOT operate vehicle on a 2-wheel dynamometer if the DO NOT TEST column is marked.

ACURA

ACURA

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Integra							
1996-2001	X
Legend							
1986-92	X
1993-95	X	X ⁽²⁾	...
MDX							
2001-02	X	...	X
2003	X	...	X ⁽¹⁾	X
NSX							
1991-2001	...	X	X ⁽³⁾	...
2002-03	...	X	X ⁽²⁾	...
RSX							
2002-03	X
SLX							
1996-99	X ⁽⁴⁾
Vigor							
1991-94	X
2.2CL							
1997	X

2.3CL							
1998-99	X
3.0CL							
1997-99	X
3.2CL							
2001	X	X ⁽³⁾	...
2002-03	X	X ⁽¹⁾	...
3.5 RL							
1996-99	X	X ⁽¹⁾	...
2000-01	X	X ⁽¹⁾	...
2002-03	X	X ⁽¹⁾	...
2.5 TL							
1996-98	X
3.2TL							
1996-98	X
1999	X	X ⁽¹⁾	...
2000-01	X	X ⁽¹⁾	...
2002-03	X	X ⁽¹⁾	...
<p>(1) Turn ignition on. Push TCS/VSA/VSA-OFF switch located on left side of dash. Indicator light will illuminate when system is disabled.</p> <p>(2) Turn ignition on. Push TCS switch located under trip set knob. TCS indicator light will illuminate when system is disabled..</p> <p>(3) Start engine. Push TCS switch located in instrument panel. TCS indicator light will illuminate when system is disabled.</p> <p>(4) Shift transfer case to 2H.</p>							

ALFA ROMEO

ALFA ROMEO

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
164							
1991-95	X
Milano							
1987-89	...	X
Spider							
1980-91	...	X

AM GENERAL

AM GENERAL

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Hummer							
1992-2003	X ⁽¹⁾	...	X
(1) Cannot be shifted into 2WD.							

AMERICAN MOTORS

AMERICAN MOTORS

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
AMX							
1980	...	X
Concord							
1980-83	...	X
Eagle With Select Drive							
1980-87	X	...	X
Eagle Without Select Drive							
1980-87	X ⁽¹⁾	...	X
Pacer							
1980	...	X
Spirit							
1980-83	...	X
(1) Cannot be shifted into 2WD.							

AUDI

AUDI

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
80 & 90							
1988-91	X
80 & 90 Quattro							
1990-91 AWD	X ⁽¹⁾	...	X
100 & 200							
1989-94	X
100 & 200 Quattro							
1989-94 AWD	X ⁽¹⁾	...	X
4000							

1980-87	X
4000 Quattro							
1984-87 AWD	X ⁽¹⁾	...	X
5000							
1980-88	X
5000 Quattro							
1985-88 AWD	X ⁽¹⁾	...	X
A4 & A4 Avant							
1996-2001	X	X ⁽²⁾	...
A4 & A4 Avant							
2002-03 FWD	X	X ⁽⁴⁾	...
A4 & A4 Avant							
2002-03 AWD	X ⁽¹⁾	...	X
A4 Quattro							
1996-2001	X ⁽¹⁾	X ⁽⁵⁾	X
A6 & A6 Avant							
1995	X
1996-2001	X	X ⁽²⁾	...
2002-03 AWD	X ⁽¹⁾	...	X
2002-03 FWD	X	X ⁽⁴⁾	...
A6 Quattro							
1995-2001	X ⁽¹⁾	X ⁽⁵⁾	X
2002-03	X ⁽¹⁾	...	X
A8							
1997-99 FWD	X	X ⁽²⁾	...
2000-03 AWD	X ⁽¹⁾	X ⁽⁴⁾	X
A8 Quattro							
1997-2001	X ⁽¹⁾	X ⁽⁵⁾	X
Allroad							
2001-03	X ⁽¹⁾	X ⁽⁴⁾	X
Cabriolet							
1995-99	X
Coupe							
1980-87	X
Coupe Quattro							
1982-87	X ⁽¹⁾	...	X

S4 & S4 Avant							
1992-94	X ⁽¹⁾	...	X
2002-02	X ⁽¹⁾	X ⁽⁴⁾	X
S4 Quattro							
2000-01	X ⁽¹⁾	X ⁽³⁾	X
S6 & S6 Avant							
1995	X ⁽¹⁾	...	X
2002-03	X ⁽¹⁾	X ⁽⁴⁾	X
S8							
2002-03	X ⁽¹⁾	X ⁽⁴⁾	X
TT Coupe							
2000-01	X	X ⁽²⁾	X
2002-03	X	X ⁽⁴⁾	...
TT Coupe Quattro							
2000-01	X ⁽¹⁾	X ⁽³⁾	X
2002-03	X ⁽¹⁾	X ⁽⁴⁾	X
V7 Quattro							
1989-94	X ⁽¹⁾	...	X
<p>(1) Cannot be shifted into 2WD.</p> <p>(2) To disable, press ASR switch, located above radio. ASR warning light will illuminate when system is disabled.</p> <p>(3) Traction control cannot be disabled.</p> <p>(4) To disable, press ESP switch, located on center console. ESP warning light will illuminate when system is disabled.</p> <p>(5) Information from manufacturer is not available at time of publication.</p>							

BMW

BMW

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
318							
1983-93	...	X
1994-96	...	X	X ⁽¹⁾	...
318 is							
1997-99	...	X	X ⁽¹⁾	...

318ti							
1997-99	...	X	X ⁽²⁾	...
320							
1980-83	...	X
323							
1998-2000	...	X	X ⁽¹⁾	...
325							
1984-93	...	X
1994-95	...	X	X ⁽¹⁾	...
325Ci							
2001-03	...	X	X ⁽³⁾	...
325i							
2001-03	...	X	X ⁽³⁾	...
325ix							
1988-91	X ⁽⁴⁾	...	X
325xi							
2001-03	X ⁽⁴⁾	...	X
328							
1996-2000	...	X	X ⁽¹⁾	...
330Ci							
2001-03	...	X	X ⁽³⁾	...
330i							
2001-03	X ⁽³⁾	...
330xi							
2001-03	X ⁽⁴⁾	...	X
524							
1985-86	...	X
525							
1989-90	...	X
1991-95	...	X	X ⁽¹⁾	...
525i							
2001-2003	...	X	X ⁽¹⁾	...
528							
1980-88	...	X
1997-2000	...	X	X ⁽¹⁾	...
530i							

1994-95	...	X	X ⁽¹⁾	...
2001-03	...	X	X ⁽¹⁾	...
535							
1985-90	...	X
1991-93	...	X	X ⁽¹⁾	...
540							
1993-2003	...	X	X ⁽¹⁾	...
633, 635 & L6							
1980-89	...	X
733, 735 & L7							
1985-90	...	X
1991-92	...	X	X ⁽¹⁾	...
740							
1993-2001	...	X	X ⁽¹⁾	...
745i							
2002-2003	...	X	X ⁽⁵⁾	...
745Li							
2002-2003	...	X	X ⁽⁵⁾	...
750							
1988-90	...	X
1991-2001	...	X	X ⁽¹⁾	...
760Li							
2003	...	X	X ⁽⁵⁾	...
840 & 850							
1991-97	...	X	X ⁽¹⁾	...
M Coupe & Convertible							
1999-2002	...	X	X ⁽¹⁾	...
M3							
1987-92	...	X
1995-2003	...	X	X ⁽¹⁾	...
M5							
1987-90	...	X
1991-93	...	X	X ⁽¹⁾	...
2000-03	...	X	X ⁽¹⁾	...
M6							
1987-92	...	X

X5							
2000-03	X ⁽⁴⁾	...	X
Z3							
1996-2000	...	X	X ⁽¹⁾	...
2001-02	...	X	X ⁽¹⁾	...
Z4							
2003	...	X	X ⁽⁵⁾	...
Z8							
2000-03	...	X	X ⁽¹⁾	...
<p>(1) The Automatic Stability Control (ASC) or Dynamic Stability Control (DSC) switch is located on center console. Indicator/warning light on instrument panel will illuminate when system is disabled.</p> <p>(2) The ASC switch is located on left side of dash. Indicator/warning light on instrument panel will illuminate when system is disabled.</p> <p>(3) The ASC or Dynamic Stability Control (DSC) switch is located on center console. Indicator/warning light on instrument panel will illuminate when system is disabled. On models with DSC and Automatic Differential Braking (ADB), depress and hold DSC switch button for 3 seconds. The DSC and Yellow brake warning lights will stay illuminated the entire time the ADB, DSC and the Dynamic Brake Control (DBC) systems are switched off.</p> <p>(4) Cannot be shifted into 2WD.</p> <p>(5) Information from manufacturer is not available at time of publication.</p>							

BUICK

BUICK - CARS

Application	FWD	RWD	Part time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Century							
1980-81	...	X
1982-98	X
1999-2003	X	X ⁽⁶⁾	...
Electra							
1980-84	...	X
1985-90	X
Estate Wagon							
1980-90	...	X
LeSabre							
1980-85	...	X

1986-92	X
1993-94	X	X ⁽²⁾	...
1995-99	X	X ⁽³⁾	...
2000-03	X	X ⁽⁴⁾	...
Park Avenue							
1990-91	X
1992-96	X	X ⁽⁵⁾	...
1997-2003	X	X ⁽⁴⁾	...
Reatta							
1988-91	X
Regal							
1980-87	...	X
1988-96	X
1997-98
Except SC	X	X ⁽⁵⁾	...
SC	X	X ⁽¹⁾	...
1999-2003	X	X ⁽⁷⁾	...
Riviera							
1980-93	X
1995-96	X	X ⁽⁵⁾	...
1997-99	X	X ⁽¹⁾	...
Roadmaster							
1991-96	...	X
Skyhawk							
1980	...	X
1982-89	X
Skylark							
1980-98	X
Somerset							
1985-86	X

(1) Traction control button is located on center console. TRAC OFF indicator will illuminate when system is disabled.

(2) Traction control switch is part of twilight sentinel/instrument panel dimmer assembly.

(3) Traction control button in to left of steering wheel.

(4) Traction control button in shift lever. TRAC OFF indicator will illuminate when system is disabled.

- (5) Traction control switch is on instrument panel. TRAC OFF indicator will illuminate when system is disabled.
- (6) Traction control system is disabled when transmission is in 1st or 2nd gear. TRAC OFF indicator will illuminate when system is disabled.
- (7) TRACTION switch is located on Black panel located behind the transaxle shift lever. TRAC OFF indicator will illuminate when system is disabled.

BUICK - TRUCKS

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Rendezvous							
2002-03 AWD	X ⁽¹⁾	...	X
2002-03 FWD	X	X ⁽²⁾	...

(1) Cannot be shifted to 2WD.

(2) Press TRAC OFF button located near the center console switchbank. TRAC OFF indicator light will illuminate when system is disabled.

CADILLAC

CADILLAC - CARS

Application	FWD	RWD	AWD	4WD	AWD	TCS	Do Not Test
Allante							
1987-89	X
1990-93	X	X ⁽¹⁾	...
Catera							
1997-2001	...	X	X ⁽²⁾	...
Cimarron							
1982-88	X
CTS							
2003	X	X ⁽⁵⁾	...
DeVille							
1980-84	...	X
1985-91	X
1992-94	X	X	X
1995-99	X	X ⁽⁵⁾	...
2000-03	X	X ⁽⁴⁾	...
Eldorado							
1980-92	X

1987-96	X
Corvette							
1980-91	...	X
1992-2003	...	X	X ⁽⁷⁾	...
Impala							
1980-96	...	X
2000-03	X	X ⁽⁴⁾	...
Lumina							
1990-2001	X
Lumina APV							
1990-96	X
Malibu							
1980-83	...	X
1997-2003	X
Metro							
1998-2001	X
Monte Carlo							
1981-88	...	X
1995-99	X
2000-03	X	X ⁽⁵⁾	...
Monza							
1980	...	X
Nova							
1985-88	X
Prizm							
1998-2002	X
Spectrum							
1985-88	X
Sprint							
1985-91	X
Venture							
1997-2003	X	X ⁽⁶⁾	...

(1) Press ASR button, located on console. ASR OFF indicator light will illuminate when system is disabled.

(2) ETS system will not operate when A/T selector is in 1 or 2 position. ETS indicator light will stay on when system is disabled..

(3) Press ETS button, located on instrument panel. TRAC OFF indicator light will illuminate when system is disabled.

- (4) Press TRAC OFF button on left side of dash. Chime will sound. SERVICE TRACTION SYSTEM indicator light will illuminate when system is disabled.
- (5) Press TRAC ON/OFF button on center console. Chime will sound. TRACTION CONTROL indicator light will illuminate when system is disabled.
- (6) Press TCS button on dash or center console. TRAC OFF indicator light will illuminate when system is disabled.
- (7) Press sliding car icon on the console. TRACTION SYSTEM OFF will illuminate when system is disabled.

CHEVROLET TRUCKS

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Astro Van							
1985-2003 RWD	...	X
1990-2003 AWD	X ⁽¹⁾ , (2)	...	X
Avalanche							
2001	...	X	X ⁽³⁾
2002 2WD	...	X	X ⁽⁹⁾	...
2003 2WD	...	X	X ⁽⁵⁾	...
2002-03 4WD	X	X
Blazer							
1980-94 2WD	...	X
1980-94 4WD	...	X	X ⁽⁴⁾
1995-2003 With Push Button Shift Selector 4WD	...	X	X ⁽³⁾
1995-98 AWD	X ⁽²⁾
1999-2003 A/T	...	X	X ⁽³⁾
Cutaway/RV Cutaway (C-Series)							
1990-2002	...	X
2003	...	X	X ⁽⁸⁾	...
C10-30 & C1500-3500 Series							
1980-2002	...	X
El Camino							
1980-87	...	X
Express Van							
1996-2003	...	X

G10-30 & G1500-3500 Series							
1980-2000	...	X
K10-30 & K1500-3500 Series							
1980-2000 With Shift Lever Selector	...	X	X ⁽⁴⁾
1996-2000 With Push Button Shift Selector	...	X	X ⁽³⁾
1998-2000 With Automatic Selector	...	X	X ⁽³⁾
LUV							
1980-82 2WD	...	X
1980-82 4WD	...	X	X ⁽⁴⁾
R10-30 & R1500-3500 Series							
1987-91	...	X
Sierra & Silverado							
1999 2WD	...	X
2000-03 2WD	...	X	X ⁽⁷⁾	...
1999-2003 With Shift Lever Selector 4WD	...	X	X ⁽⁴⁾
1999-2003 With Push Button Shift Selector 4WD	...	X	X ⁽³⁾
1999-2003 With Automatic Selector	...	X	X ⁽³⁾
1999-2003 AWD	X ⁽¹⁾	...	X
SSR							
2003	...	X	X ⁽⁵⁾	...
Suburban							
1980-2001 2WD	...	X
2002-2003 2WD	...	X	X ⁽⁵⁾	...
1980-99 With Shift Lever Selector 4WD	...	X	X ⁽⁴⁾
1996-2003 With Push Button Shift Selector 4WD	...	X	X ⁽³⁾
1998-2003 With Automatic Selector	...	X	X ⁽³⁾
S10 & S15 Pickup							
1982-2003 2WD	...	X
S-Series							
2002-03	...	X

Tahoe							
1995-99 2WD	...	X
2000-03 2WD	...	X	X ⁽⁷⁾	...
1995-99 With Shift Lever Selector 4WD	...	X	X ⁽⁴⁾
1996-2003 With Push Button Shift Selector 4WD	...	X	X ⁽³⁾
1998-2003 With Automatic Selector	...	X	X ⁽³⁾
Tracker							
1998-2003 2WD	...	X
1998-2003 2WD	...	X	X ⁽⁴⁾
TrailBlazer							
2002-03 2WD	...	X	X ⁽⁶⁾	...
2002-03 NVG126-NP4 Transfer Case Full-Time AWD	X ⁽¹⁾	...	X
2002-03 NVG126-NP4 Transfer Case Part-Time 4WD	...	X	X ⁽³⁾
T10 & T15 Pickup							
1982-97 With Shift Lever Selector 4WD	...	X	X ⁽⁴⁾
1994-2001 With Push Button Shift Selector 4WD	...	X	X ⁽³⁾
1999-2001 With Automatic Shift Selector	...	X	X ⁽³⁾
Venture							
2002-2003 AWD	X ⁽¹⁾	...	X
2002-2003 2WD	X	X ⁽⁵⁾	...

(1) Cannot be shifted to 2WD.

(2) All wheel drive is optional.

(3) Press button on instrument panel to select 2HI position. Switch indicator light will flash until new position is active. Indicator light will stay on.

(4) Shift transfer case to 2WD or 2H mode.

(5) Information from manufacturer is not available at time of publication.

(6) Press traction control switch located on instrument panel. Indicator light will illuminate when system is disabled.

Press OFF/ON sliding car icon located near the shift lever. TRAC OFF indicator

(7) light will illuminate when system is disabled.

(8) Press TRACTION ASSIST switch located left of the steering wheel. TRACTION OFF indicator light will illuminate when system is disabled.

(9) Press the switch with the sliding car icon, located left of the steering wheel on the instrument panel. TRACTION OFF will illuminate when system is disabled.

CHRYSLER

CHRYSLER - CARS

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Cirrus							
1995-2000	X
Concorde							
1993-2001	X	X ⁽¹⁾	...
2002-2003	X	X ⁽³⁾	...
Conquest							
1987-89	X
Cordoba							
1980-83	...	X
E Class							
1983-84	X
Executive							
1983-85	X
Fifth Avenue							
1983-89	...	X
1990-93	X
Imperial							
1981	...	X
1990-93	X
Laser							
1984-87	X
LeBaron							
1980-81	...	X
1982-95	X
LeBaron GTS							
1985-89	X
LHS							
1994-2001	X

						X ⁽¹⁾	
New Yorker							
1980-83	...	X
1983-93	X
1994-96	X	X ⁽¹⁾	...
Newport							
1980-81	...	X
Prowler							
2001-02	...	X
Sebring Convertible							
1996-97	X
1998-2000	X	X ⁽³⁾	...
2001-03	X
Sebring Coupe							
1995-2000	X
2001-03	X	X ⁽²⁾	X
Sebring Sedan							
2001-03	X
TC							
1989-91	X
300							
1980	...	X
300M							
1999-2001	X	X ⁽¹⁾	...
2002-2003	X	X ⁽³⁾	...
<p>(1) Press TRAC OFF switch on instrument panel. Indicator light will illuminate when system is disabled.</p> <p>(2) Traction control cannot be disabled.</p> <p>(3) Traction control switch is to the right of the steering column. Indicator light will illuminate when system is disabled.</p>							

CHRYSLER - TRUCKS

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
PT Cruiser							
2001-03	X	X ⁽¹⁾	...
Town & Country							
1980-81	...	X

1982-88	X
1990-96	X
1991-96 AWD	X ⁽³⁾	...	X
1997-2003 AWD	X ⁽³⁾	X ⁽¹⁾	X
1997-2002 FWD	X	X ⁽¹⁾	...
2003 FWD	X	X ⁽²⁾	...

Voyager

2001 AWD	X ⁽³⁾	X ⁽¹⁾	X
2003 FWD	X	X ⁽¹⁾	...

(1) Press TRAC OFF switch on instrument panel. Indicator light will illuminate when system is disabled.

(2) Press TRAC OFF switch, located on top of the steering column. Indicator light will illuminate when system is disabled.

(3) Cannot be shifted to 2WD.

DAEWOO

DAEWOO

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Lanos							
1999-2001	X
Leganza							
1999-2001	X	X ⁽¹⁾	X
Nubria							
1999-2001	X

(1) Traction control cannot be disabled.

DAIHATSU

DAIHATSU

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Charade							
1988-92	X
Rocky							
1990-92	X ⁽¹⁾

(1) Shift transfer case to 2H position. Place locking hub to FREE position at front axle.

DODGE

DODGE - CARS

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Aries							
1981-89	X
Aspen							
1980	...	X
Avenger							
1995-2000	X
Challenger							
1980-83	...	X
Charger							
1983-87	X
Colt							
1980-94 FWD	X
1980 RWD	...	X
Colt Vista Wagon							
1984-94 2WD	X
1984-94 AWD	X ⁽²⁾	...	X
Conquest							
1984-86	...	X
Daytona							
1984-93	X
Diplomat							
1980-89	...	X
Dynasty							
1988-93	X
Intrepid							
1993-2003	X	X ⁽¹⁾	...
Lancer							
1985-89	X
Mirada							
1980-83	...	X
Monaco							
1990-92	X
Neon							
1995-99	X

2000-03	X	X ⁽¹⁾	...
Omni							
1980-90	X
Rampage							
1982-84	X
Shadow							
1987-94	X
Spirit							
1989-95	X
Stealth							
1991-96 2WD	X
1991-96 AWD	X ⁽²⁾	...	X
Stratus Coupe							
2001-03	X	X ⁽³⁾	...
Stratus Sedan							
1995-2003	X
St. Regis							
1980-81	...	X
Viper							
1992-2003	...	X
024							
1980-82	X
400							
1982-83	X
600							
1983-88	X
(1) Press TRAC OFF switch on instrument panel to disable system. Indicator light will illuminate when system is disabled.							
(2) Cannot be shifted to 2WD.							
(3) Traction control cannot be disabled.							

DODGE/ PLYMOUTH - TRUCKS

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Arrow Pickup							
1980-83	...	X
B-Series Ram Van/Wagon							
1980-2003	...	X

Cab & Chassis							
1990-2003 2WD	...	X
1990-2003 4WD	X	X
Caravan/Grand Caravan & Voyager							
1991-96 AWD	X ⁽¹⁾	...	X
1997-2003 AWD	X ⁽¹⁾	X ⁽²⁾	X
1984-96 FWD	X
1997-2003 FWD	X	X ⁽²⁾	...
Dakota							
1987-99 4WD	...	X	X ⁽³⁾
2000 NV231 4WD	...	X	X ⁽³⁾
2000 NV242 AWD	X ⁽¹⁾	...	X
2001-03 NV233 4WD	...	X	X ⁽⁴⁾
2001-03 NV244 AWD	X ⁽¹⁾	...	X
Durango							
1998-2003 2WD	...	X
1998-99 4WD	...	X	X ⁽³⁾
2000 NV231 4WD	...	X	X ⁽³⁾
2000 NV242 AWD	X ⁽¹⁾	...	X
2001-03 NV233 4WD	...	X	X ⁽⁴⁾
2001-03 NV244 AWD	X ⁽¹⁾	...	X
D50 Pickup							
1980	...	X
D-Series Full Size Pickup							
1980-2003 2WD	...	X
1990-2003 4WD	X	X
Mini Ram Van							
1984-91	X
Raider							
1987-89 2WD	...	X
1987-89 4WD	...	X	X ⁽³⁾
Ramcharger							
1980-93 2WD	...	X
1980-93 4WD	...	X	X ⁽³⁾

Ram Pickup (1500-3500)							
1994-2003 2WD	...	X
1994-2003 4WD	...	X	X ⁽³⁾
Ram Van/Wagon							
1990-2003	...	X
Ram-50							
1982-93 2WD	...	X
1982-93 4WD	...	X	X ⁽³⁾
Scamp							
1983	X
Sprinter							
2003	...	X
Trailduster							
1980-81 2WD	...	X
1980-81 4WD	...	X	X ⁽³⁾
Voyager Full Size Van							
1980-83	...	X
W-Series Pickup							
1980-93	...	X	X ⁽³⁾
<p>(1) Cannot be shifted to 2WD.</p> <p>(2) Press TRAC OFF switch on instrument panel. Indicator light will illuminate when system is disabled.</p> <p>(3) Shift transfer case lever to 2WD or 2H position</p> <p>(4) Press selector switch on instrument panel. Switch indicator light will flash until new position is active. The indicator light will stay on.</p>							

EAGLE

EAGLE

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Eagle							
1988	X ⁽¹⁾
Medallion							
1988-89	X
Premier							
1988-92	X
Summit							

1989-96	X
Summit Wagon							
1992-96 2WD	X
1992-98 AWD	X ⁽²⁾	...	X
Talon							
1990-98 2WD	X
1989-98 AWD	X ⁽²⁾	...	X
Vision							
1993-97	X	X ⁽³⁾	...
<p>(1) Mode selector is located in instrument panel. To change mode, stop vehicle. Pull and hold lock pin down, then move switch lever to 2WD. It may be necessary to move vehicle forward or backwards to disengage axle and transfer case.</p> <p>(2) Cannot be shifted to 2WD.</p> <p>(3) Press switch on instrument panel. TRAC OFF light will illuminate when system is disabled.</p>							

FIAT

FIAT

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Bravada							
1980-91	...	X
Spider 2000							
1980-83	...	X
Strada							
1980-82	X
X1/9							
1980-83	...	X

FORD

FORD - CARS

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Aspire							
1994-97	X
Contour							
1995-98	X
1999-2000	X	X ⁽²⁾	...

Crown Victoria							
1983-91	...	X
1992-95	...	X	X ⁽¹⁾	X
1996-97	...	X	X ⁽¹⁾	X
1998-2000	...	X	X ⁽³⁾	...
2003	...	X	X ⁽²⁾	...
Custom 500							
1980-82	...	X
Escort, EXP & ZX2							
1981-2002	X
Fairmont							
1980-83	...	X
Festiva							
1987-93	X
Fiesta							
1980	X
Focus							
2000-02	X
2003	X	X ⁽⁶⁾	...
Granada							
1980-82	...	X
LTD							
1980-86	...	X
Mustang							
1980-98	...	X
1999-2000	...	X	X ⁽⁴⁾	...
2001	...	X	X ⁽²⁾	...
2002-2003	...	X	X ⁽⁹⁾	...
Pinto							
1980	...	X
Probe							
1989-97	X
Taurus							
1986-99	X
2000-03	X	X ⁽⁵⁾	...
Tempo 2WD							
1984-94	X

Tempo 4WD							
1987-91	X ⁽⁷⁾
Thunderbird							
1980-93	...	X
1994-96	X ⁽²⁾	...
1997	...	X	X ⁽⁸⁾	...
2002-03	...	X	X ⁽⁹⁾	...
ZX2							
2002-03	X
<p>(1) Traction control cannot be disabled.</p> <p>(2) Disable by pushing traction control switch. Indicator light will illuminate when system is disabled.</p> <p>(3) Disable by pushing TRAC button on left side of glove compartment. TRAC CNTL indicator light on instrument panel will illuminate when system is disabled.</p> <p>(4) Disable by pushing T/C OFF button in front of shift lever. Switch will illuminate when system is disabled.</p> <p>(5) Disable by pushing T/C OFF button on right side of instrument cluster. OFF indicator light will illuminate when system is disabled.</p> <p>(6) Disable by pushing TCS switch located to the right of the emergency brake. Indicator light on instrument panel will illuminate when system is disabled.</p> <p>(7) 2WD switch is located on overhead console.</p> <p>(8) Disable by pushing traction control button inside console. T/A OFF indicator light will illuminate when system is disabled.</p> <p>(9) Press OFF TRAC switch on left side of instrument panel. The switch will illuminate when the system is disabled.</p>							

FORD - TRUCKS

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Aerostar							
1985-97 2WD	...	X
1990-97 AWD	X ⁽¹⁾	...	X
Bronco							
1980-96	...	X	X ⁽²⁾
Bronco II							
1983-90	...	X	X ⁽²⁾
Club Wagon							
1980-2001	...	X

2002-2003 4WD	...	X	X ⁽³⁾
Ranger							
1983-2003 2WD	...	X
1983-1994 4WD	...	X	X ⁽²⁾
1995-97 4WD	...	X	X ⁽³⁾
1998-2003 4WD	...	X	X ⁽⁵⁾
Windstar							
1995	X
1996-98	X	X ⁽⁶⁾	...
1999-2003	X	X ⁽⁷⁾	...

(1) Cannot be shifted to 2WD.

(2) Move transfer case shifter to 2WD position.

(3) Move transfer case shifter to 2H position to shift into 2WD position. On vehicles equipped with Electronic Shift 4WD System or Control-Trac, turn switch to 2H or 2WD to shift into 2WD position. Switch is located to right of steering wheel. On vehicles with manual hubs, place hubs in FREE position.

(4) Shift transfer case lever to 2H position. Ensure 4WD indicator light is off.

(5) Turn Electronic Shift 4WD System switch to 2WD position.

(6) Push traction control switch located on center of dash or in glove compartment. The OFF indicator light will illuminate when system is disabled.

(7) Push T/C OFF switch located on center of dash. The T/C OFF indicator light will illuminate or T/C OFF message will be displayed on message center when system is disabled.

(8) Hold switch with sliding car icon for 5 seconds. Indicator light will illuminate when system is disabled.

GEO

GEO

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Metro							
1989-97	X
Prizm							
1989-97	X
Spectrum							
1989	X
Storm							
1990-93	X

2002 W/ NVG226-NP4 Transfer Case	...	X	X ⁽³⁾
G10-30 & G1500-3500 Series							
1980-2000	...	X
K10-30 & K1500-3500 Series							
1980-2000 With Lever Type Shift Selector 4WD	...	X	X ⁽⁴⁾
1996-2000 With Push Button Type Shift Selector 4WD	...	X	X ⁽³⁾
1998-2000 A/T 4WD	...	X	X ⁽³⁾
LUV							
1980-82 2WD	...	X
1980-82 4WD	...	X	X ⁽⁴⁾
R10-30 & R1500-3500 Series							
1987-91	...	X
Safari Van							
1985-2003 2WD	...	X
1990-2003 AWD	X ⁽¹⁾	X
Savana Special/Savana Camper Special/Savana Van							
1996-2003	...	X
Sierra							
1999 2WD	...	X
2000-03 2WD	...	X	X ⁽⁷⁾	...
1999-2003 With Lever Type Shift Selector 4WD	...	X	X ⁽⁴⁾
1999-2003 With Push Button Type Shift Selector 4WD	...	X	X ⁽³⁾
1999-2003 A/T 4WD	...	X	X ⁽³⁾
1999-2003 AWD	X ⁽¹⁾	...	X
Sonoma							
1990-2003 2WD	...	X
1982-97 With Shift Lever Type Selector 4WD	...	X	X ⁽⁴⁾
T10 & T15 Pickup							
1982-97 With Lever Type Shift Selector 4WD	...	X	X ⁽⁴⁾
1994-2001 With Push Button Type Shift Selector 4WD	...	X	X ⁽³⁾
1999-2001 A/T 4WD	...	X	X ⁽³⁾

2002-2003 A/T 2WD	X	X ⁽⁵⁾	...
Yukon							
1991-99 2WD	...	X
2000-02 2WD	...	X	X ⁽⁸⁾	...
2003 2WD	...	X	X ⁽⁸⁾	...
1991-99 With Lever Type Shift Selector 4WD	...	X	X ⁽⁴⁾
1996-2001 With Push Button Type Shift Selector 4WD	...	X	X ⁽³⁾
1998-2001 A/T 4WD	...	X	X ⁽³⁾

Yukon XL							
2000-01 2WD	...	X	X ⁽⁵⁾	...
2002 2WD	...	X	X ⁽⁸⁾	...
2003 2WD	...	X	X ⁽⁸⁾	...
2000-01 With Push Button Type Shift Selector 4WD	...	X	X ⁽³⁾
2000-01 A/T	...	X	X ⁽³⁾

- (1) Cannot be shifted to 2WD.
- (2) All wheel drive is optional.
- (3) Press button on instrument panel to select 2HI position. Switch indicator light will flash until new position is active. Indicator light will stay on.
- (4) Shift transfer case to 2WD or 2H mode.
- (5) Press traction control switch located in instrument panel. Indicator light will illuminate when system is disabled.
- (6) Press OFF/ON sliding car icon located near the shift lever. TRAC OFF indicator light will illuminate when system is disabled.
- (7) Press TRACTION ASSIST switch located left of the steering wheel. TRACTION OFF indicator light will illuminate when system is disabled.
- (8) Press T/C switch, located on the instrument panel. TC indicator light will illuminate when system is disabled.

HONDA

HONDA

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Accord - 4-Cylinder							
1980-2000	X

Accord - V6							
1995-97	X
1998-2003	X	X ⁽¹⁾	...
Civic							
1980-2003	X
Civic Wagon							
1987-90	X ⁽²⁾
1991-2003	X
CRX							
1984-91	X
CR-V							
1997-2000 2WD	X
1997-2002 AWD	X ⁽³⁾	...	X
Del Sol							
1992-96	X
Insight							
2000-02	X
Odyssey							
1995-98	X
1999-2003	X	X ⁽¹⁾	...
Passport							
1994-2002 2WD	...	X
1994-97 4WD	X ⁽⁴⁾
1998-2002 4WD	X ⁽⁵⁾
Prelude							
1980-2001	X
S2000							
2000-03	...	X

(1) Press TCS switch near left side vent. TCS indicator light will illuminate when system is disabled.

(2) On A/T models, locate disengagement plate on rear of transaxle case behind the right front wheel. Loosen lock bolt on plate. Turn middle bolt on plate. Turn middle bolt counterclockwise until plate rotates about 150 degrees and is stopped by lock bolt. Tighten lock bolt. On M/T models, locate Orange disengagement lever at rear of engine. Loosen lock bolt at slotted lever. Turn middle bolt on lever counterclockwise and tighten lock bolt.

(3) Cannot be shifted to 2WD.

(4) Shift transfer case lever into 2WD position. Ensure 4WD indicator light is off.

2003	X	X ⁽⁵⁾	X
FX45							
2003	...	X	X ⁽⁵⁾	...
G20							
1991-2002	X
G35							
2003	X	X ⁽⁵⁾	...
I30							
1995-97	X	X ⁽¹⁾	X
1998-2001	X	X ⁽²⁾	...
I35							
2002-03	X	X ⁽⁵⁾	...
J30							
1993-97	...	X
M30							
1990-92	...	X
M45							
2003	...	X	X ⁽⁵⁾	...
Q45							
1990-2003	...	X	X ⁽²⁾	...
QX4							
1997-1998	X	...	X
1999	...	X	X ⁽³⁾
2000-03	...	X	X ⁽⁴⁾
<p>(1) Traction control system cannot be disabled.</p> <p>(2) To disable system, push TCS switch located on console (early models) or on instrument panel (late models). The TCS-OFF indicator light will illuminate when system is disabled.</p> <p>(3) Shift transfer case lever to 2H position.</p> <p>(4) To disable system, place 4WD switch located on instrument panel in 2WD position. Indicator light on instrument panel should indicate 2WD.</p> <p>(5) Information from manufacturer is not available at time of publication.</p>							

ISUZU

ISUZU

Application	FWD	RWD	Part Time	Full Time	AWD	TCS	Do Not
-------------	-----	-----	-----------	-----------	-----	-----	--------

			4WD	4WD			Test
Ascender							
2003 2WD	...	X	X ⁽¹⁾	...
2003 4WD	...	X	X ⁽²⁾	X ⁽¹⁾	...
Amigo							
1989-2000 2WD	...	X
1989-94 4WD	...	X	X ⁽²⁾
1998-2000 4WD	...	X	X ⁽³⁾
Axiom							
2002-03 2WD	...	X
2002-03 4WD	...	X	X ⁽⁴⁾
Hombre							
1996-2000 2WD	...	X
1996-2000 4WD	...	X	X ⁽²⁾
1996-2000 4WD	...	X	X ⁽⁵⁾
I-Mark							
1981-85	...	X
1986-89	X
Impulse							
1983-89 2WD	...	X
1990-92 2WD	X
1990-92 4WD	X ⁽⁶⁾	...	X
Oasis							
1996-99	X
Pickup							
1981-95 2WD	...	X
1981-95 4WD	X ⁽²⁾
Rodeo							
1991-2003 2WD	...	X
1991-97 4WD	...	X	X ⁽²⁾
1998-2003 4WD	...	X	X ⁽³⁾
Rodeo Sport							
2001-03 2WD	...	X
2001-03 4WD	...	X	X ⁽²⁾
Stylus							
1990-93	X
Trooper							

2000	...	X	X ⁽²⁾	...
2002-03	...	X	X ⁽⁵⁾	...
XK8							
1997-2003	...	X	X ⁽³⁾	...
S-Type							
2000-03	...	X	X ⁽²⁾	...
2000-03	...	X	X ⁽⁴⁾	...
<p>(1) Press switch located on dash. Indicator light on instrument panel will illuminate when system is disabled.</p> <p>(2) Press TRAC OFF or Automatic Stability Control (ASC) switch on console near shift lever disables system. Indicator light on instrument panel will illuminate when system is disabled.</p> <p>(3) Press TRAC OFF switch is located near radio. Indicator light on instrument panel will illuminate when system is disabled.</p> <p>(4) Press Dynamic Stability Control (DSC) switch near shift lever. Indicator light will illuminate when system is disabled.</p> <p>(5) Information from manufacturer is not available at time of publication.</p>							

JEEP

JEEP

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
CJ5 & CJ7							
1980-86	...	X	X ⁽¹⁾
Cherokee							
1980-2001 2WD	...	X
1980-2001 4WD	...	X	X ⁽¹⁾
1980-86 4WD Select-Trac	...	X	X ⁽²⁾
1987-92 4WD Select-Trac	X ⁽³⁾	X
Comanche							
1986-93 2WD	...	X
1986-93 4WD	...	X	X ⁽¹⁾
Grand Cherokee							
1993-2003 2WD	...	X
1993-2003 With Quadra Trac 4WD	X ⁽²⁾	...	X
1993-2003 Except Quadra	...	X	X ⁽⁴⁾

2002	X	X ⁽³⁾	...
2003	X
Rio							
2001-03	X
Sedona							
2002-03	X
Sephia							
1994-2001	X
Sorento							
2003 2WD	...	X
2003 4WD	...	X	X ⁽²⁾
Spectra							
2001-02	X
Sportage							
1995-2002 2WD	...	X
1995-2002 4WD	...	X	X ⁽¹⁾
<p>(1) Shift transfer case lever to 2H position.</p> <p>(2) Turn transfer knob from 2HI to 4HI mode. No need to depress clutch or put into Neutral.</p> <p>(3) TCS switch is below the left vent. Indicator light will illuminate when system is disabled.</p>							

LAND ROVER

LAND ROVER

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Defender 90							
1994-98	X	...	X
Discovery							
1987-98	X	...	X
Discovery II							
1999-2003	X	X ⁽¹⁾	X
Freelander							
2002-03	X	...	X
Range Rover							
1987-94	X	...	X
1995-2003	X		X

X⁽¹⁾

(1) Information from manufacturer is not available at time of publication.

LEXUS**LEXUS**

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
ES250							
1990-91	X
ES300							
1992-96	X
1997-2003	X	X ⁽⁵⁾	...
GS300							
1993-97	...	X	X ⁽¹⁾	...
1998-2003	...	X	X ⁽⁴⁾	...
GS400							
1998-2000	...	X	X ⁽⁴⁾	...
GS430							
2001-03	...	X	X ⁽⁴⁾	...
GX 470							
2003	X ⁽³⁾	...	X
IS300							
2001-03	...	X	X ⁽²⁾	...
LS400							
1990-2000	...	X	X ⁽⁴⁾	...
LS430							
2001-02	...	X	X ⁽²⁾	...
2003	...	X	X ⁽¹⁾	...
LX450							
1996-97	X ⁽³⁾	...	X
LX470							
1998-2003	X ⁽³⁾	...	X
RX300							
2002-2003 2WD	X	X ⁽⁶⁾	...
1999-2003 4WD	X ⁽³⁾	X ⁽⁶⁾	X

2003	...	X	X ⁽⁸⁾	...
Mark VI							
1980-83	...	X
Mark VII							
1983-92	...	X
Mark VIII							
1993-96	...	X	X ⁽⁶⁾	...
1997-98	...	X	X ⁽⁷⁾	...
Navigator							
1998-2002 2WD	...	X
2003 2WD	...	X	X ⁽⁸⁾	...
1998 4WD	...	X	X ⁽³⁾
1999-2003 4WD	X ⁽⁴⁾	...	X
Town Car							
1982-91	...	X
1992-97	...	X	X ⁽⁵⁾	X
1998-2001	...	X	X ⁽⁶⁾	...
2002-2003	...	X	X ⁽⁸⁾	...
Versailles							
1980	...	X

- (1) On models equipped with traction control system, disable system from Message Center or left of the steering wheel.. T/C OFF Indicator light will illuminate when system is disabled.
- (2) Push OFF TRAC button to disable traction control system. Also, push OFF ATS button to disable Advance Trac Stability (ATS) enhancement system. Indicator light on buttons will illuminate when systems are disabled.
- (3) To shift into 2WD, shift transfer case into 2H position. On vehicles equipped with Electronic Shift 4WD system or Control-Trac, turn switch to 2H or 2WD position. On models with manual hubs, place hubs in FREE position.
- (4) Cannot be shifted to 2WD.
- (5) Traction control system cannot be disabled.
- (6) Push TRACTION ASSIST or VSC OFF switch to disable traction control. OFF indicator light will illuminate when system is disabled.
- (7) Flip traction control toggle switch. Indicator light will illuminate when system is disabled.
- (8) Push switch that has a spinning wheel or sliding car icon on it. Indicator light will illuminate when system is disabled.

MAZDA

MAZDA

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
B2000							
1980-87	...	X
B2200							
1982-93	...	X
B2300							
1994-03 2WD	...	X
1994-2003 4WD	X ⁽²⁾
B2500							
1998-2001	...	X
B2600							
1987-93 2WD	...	X
1987-93 4WD	...	X	X ⁽¹⁾
B3000 & B4000							
1994-2003 2WD	...	X
1994-2003 4WD	...	X	X ⁽²⁾
GLC							
1980-83	...	X
1981-85	X
Miata/MX-5 Miata							
1990-2003	...	X
Millenia							
1995-2002	X	X ⁽³⁾	...
MPV							
1989-98 2WD	...	X
2001-03 2WD	X	X ⁽⁵⁾	...
1989-98 4WD	...	X	X ⁽⁶⁾
MX3							
1992-95	X
MX6							
1988-97	X
Navajo							
1991-94 2WD	...	X
1991-94 4WD	...	X	X ⁽²⁾

Protege							
1990-2003 2WD	X
1994-94 AWD	X ⁽⁴⁾	...	X
Protege 5							
1990-2003	X
RX-7							
1980-95	...	X
Tribute							
2001-03 2WD	...	X
2001-03 4WD	X ⁽⁴⁾	X
6							
2003	X	X ⁽⁵⁾	...
323							
1986-94	X
323 Turbo							
1987-89	X ⁽⁴⁾	...	X
626							
1980-82	...	X
1983-97	X
1998-2002	X	X ⁽⁵⁾	...
929							
1988-95	...	X
<p>(1) Shift transfer case lever to 2H position.</p> <p>(2) On vehicles with automatic transfer case, twist knob located on instrument panel to 2WD position. On vehicles with manual transfer case, move lever to 2H.</p> <p>(3) To disable system, press TCS OFF button located near shift lever. TCS OFF indicator light will illuminate when system is disabled.</p> <p>(4) Cannot be shifted to 2WD.</p> <p>(5) To disable system, press TCS button located on left side of dash. TCS OFF indicator light will illuminate when system is disabled.</p> <p>(6) Push shift switch from 4WD to 2WD. A beep will sound to indicate switch.</p>							

MERCEDES-BENZ

MERCEDES-BENZ

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
C32							

2002-03	...	X	X ⁽¹⁾	...
C36 AMG							
1995-97	...	X	X ⁽¹⁾	...
C43 AMG							
1998-2000	...	X	X ⁽¹⁾	...
C220							
1994	...	X	X ⁽³⁾	X
1995-2000	...	X	X ⁽¹⁾	...
C230							
1997-2003	...	X	X ⁽¹⁾	...
C240							
2001-02 2WD	...	X	X ⁽¹⁾	...
C240							
2003 AWD	X ⁽⁴⁾	X ⁽¹⁾	X
C280							
1994	...	X	X ⁽³⁾	X
1995-2000	...	X	X ⁽¹⁾	...
C320							
2001-03 2WD	...	X	X ⁽¹⁾	...
2003 AWD	X ⁽⁴⁾	X ⁽¹⁾	X
CL55 AMG							
2001-03	...	X	X ⁽¹⁾	...
CL500 & CL600							
1998-2003	...	X	X ⁽¹⁾	...
CLK55 AMG							
2001-03	...	X	X ⁽¹⁾	...
CLK320							
1998-2003	...	X	X ⁽¹⁾	...
CLK430							
1999-2003	...	X	X ⁽¹⁾	...
CLK500							
2003	...	X	X ⁽¹⁾	...
E55 AMG							
1999-2003	...	X	X ⁽¹⁾	...
E300							

1995-99	...	X	X ⁽¹⁾	...
E320							
1994-95	...	X	X ⁽³⁾	X
1996-2003	...	X	X ⁽¹⁾	...
E320 4MATIC							
1998-2003	X ⁽⁴⁾	X ⁽¹⁾	X
E420							
1994-95	...	X	X ⁽³⁾	X
1997	...	X	X ⁽¹⁾	...
E430							
1998-2002	...	X	X ⁽¹⁾	...
E430 4MATIC							
1998-2002	...	X	X ⁽⁴⁾	X ⁽¹⁾	X
E500							
1994	...	X	X ⁽³⁾	X
2003	...	X	X ⁽¹⁾	...
G55							
2003	X ⁽⁴⁾	...	X ⁽¹⁾	X
G500							
2002-03	X ⁽⁴⁾	X ⁽¹⁾	X
ML55							
2000-03	X ⁽⁴⁾	X ⁽¹⁾	X
ML320							
1998-2003	X ⁽⁴⁾	X ⁽¹⁾	X
ML350							
2003	X ⁽⁴⁾	...	X ⁽¹⁾	X
ML430							
1999-2001	X ⁽⁴⁾	X ⁽¹⁾	X
ML500 AMG							
2002-03	X ⁽⁴⁾	X ⁽¹⁾	X
S320, S350, S420, S500 & S600							
1994	...	X	X ⁽³⁾	X
S320, S420, S500 & S600							
1995-99	...	X	X ⁽¹⁾	...
S430/S500							

2000 2WD	...	X	X ⁽¹⁾	...
2003 AWD	X ⁽⁴⁾	X ⁽¹⁾	X
S430, S500, S55 AMG & S600							
2001-03	...	X	X ⁽¹⁾	...
SL55							
2003	...	X	X ⁽²⁾	...
SL320, SL500 & SL600							
1994	...	X	X ⁽³⁾	X
1995-97	...	X	X ⁽¹⁾	...
SL500							
2003	...	X	X ⁽²⁾	...
SL500 & SL600							
1989-02	...	X	X ⁽¹⁾	...
SLK32							
2002-2003	...	X	X ⁽¹⁾	...
SLK230							
1998-2003	...	X	X ⁽¹⁾	...
SLK320							
2001-03	...	X	X ⁽¹⁾	...
190D							
1984	...	X
190E							
1984-93	...	X
240D							
1980-83	...	X
260E							
1986-93	...	X
280CE, 280E & 280SE							
1980-81	...	X
300CD, 300D, 300SD & 300TD							
1980-85	...	X
300E, 300CE & 300TE							
1986-90	...	X
1991-93	...	X	X ⁽³⁾	X
300E 4MATIC							
1990-93	...	X	X ⁽⁴⁾	X ⁽³⁾	X

300D & 300 TD

1986-90	...	X
1991-93	...	X	X ⁽³⁾	X

300SD

1992-93	...	X	X ⁽³⁾	X
---------	-----	---	-----	-----	-----	------------------	---

300SDL

1986-87	...	X
---------	-----	---	-----	-----	-----	-----	-----

300SE & 300SEL

1986-90	...	X
1991-93	...	X	X ⁽³⁾	X

300SL

1991-93	...	X	X ⁽³⁾	X
---------	-----	---	-----	-----	-----	------------------	---

350SD & 350SDL

1990	...	X
1991	...	X	X ⁽³⁾	X

380SE, 380SEC, 380SEL, 380SL & 380SLC

1981-85	...	X
---------	-----	---	-----	-----	-----	-----	-----

300TE

1990-1993	X	...	X
-----------	-----	-----	-----	-----	---	-----	---

400E

1992-93	...	X	X ⁽³⁾	X
---------	-----	---	-----	-----	-----	------------------	---

400SE & 400SEL

1992-93	...	X	X ⁽³⁾	X
---------	-----	---	-----	-----	-----	------------------	---

420SEL

1986-90	...	X
1991	...	X	X ⁽³⁾	X

450SL, 450SEL & 450SLC

1980	...	X
------	-----	---	-----	-----	-----	-----	-----

500E

1992-93	...	X	X ⁽³⁾	X
---------	-----	---	-----	-----	-----	------------------	---

500SEC & 500SEL

1984-85	...	X
---------	-----	---	-----	-----	-----	-----	-----

500SEC, 500SEL, 600SEC & 600SEL

1992-93	...	X	X ⁽³⁾	X
---------	-----	---	-----	-----	-----	------------------	---

500SL

1991-93	...	X	X ⁽³⁾	X
---------	-----	---	-----	-----	-----	------------------	---

560SEC & 560SEL

1981-87	X
Marquis							
1980-86	...	X
Marauder							
2003	...	X	X ⁽⁴⁾	...
Monarch							
1980	...	X
Mountaineer							
1997-2003 2WD	...	X	X ⁽¹⁾	...
1997-2003 AWD	X ⁽⁵⁾	...	X
Mystique							
1995-98	X	X ⁽⁶⁾	...
1999-2000	X	X ⁽¹⁾	...
Sable							
1986-99	X
2000-01	X	X ⁽¹⁾	...
2002	X	X ⁽⁴⁾	...
2003	X	X ⁽¹⁾	...
Topaz							
1984-94 2WD	X
1987-91 4WD	X	X ⁽⁷⁾
Tracer							
1987-99	X
Villager							
1993-2002	X
XR7							
1980-93	...	X
1994-96	...	X	X ⁽¹⁾	...
1997	...	X	X ⁽¹⁾	...
1999-2002	X	X ⁽¹⁾	...
Zephyr							
1980-83	...	X

(1) Push traction control switch to disable system. The indicator light will illuminate when system is disabled.

(2) Traction control system cannot be disabled.

Push traction control button on left side of dash to disable system. The TRAC CNTL

- (3) indicator light will illuminate when system is disabled.
- (4) Push traction control switch. Switch will either click into a toggle-off position or will no longer be illuminated.
- (5) Cannot be shifted to 2WD.
- (6) Push T/C OFF button on left side of dash to disable system. The TRACTION CONTROL indicator light will illuminate when system is disabled.
- (7) Press switch on overhead console to shift system into FWD mode.

MERKUR

MERKUR

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Scorpio							
1988-89	...	X
XR4Ti							
1985-89	...	X

MG

MG

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
MGB							
1980	...	X

MINI

MINI

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Cooper							
2002-03	X
Cooper S							
2002-2003	X	X ⁽¹⁾	...
(1) Information from manufacturer is not available at time of publication.							

MITSUBISHI

MITSUBISHI

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
-------------	-----	-----	---------------	---------------	-----	-----	-------------

Cordia							
1983-88	X
Diamante							
1992-95	X
1996	X	X ⁽¹⁾	...
1997-98	X
1999-2000	X	X ⁽²⁾	...
Eclipse							
1990-2002	X ⁽⁴⁾	...	X
Expo							
1990-99 2WD	X
2000-2003 2WD	X	X ⁽³⁾	X
1992-96 4WD	X ⁽⁴⁾	...	X
Galant							
1984-98 2WD	X
1999-2002 2WD	X	X ⁽³⁾	X
1989-93 4WD	X ⁽⁴⁾	X
Lancer							
2002-03	X
Mirage							
1985-2002	X
Montero							
1983-91	...	X	X ⁽⁵⁾
1992-2003	...	X	X ⁽⁶⁾
Montero Sport							
1997-2003 2WD	...	X
1997-2003 4WD	...	X	X ⁽⁵⁾
Outlander							
2003 FWD	X
2003 AWD	X ⁽⁴⁾	...	X
Pickup							
1983-96 2WD	...	X
1983-96 4WD	...	X	X ⁽⁵⁾
Precis							
1987-93	X
Sigma							
1989-90	X

Starion							
1983-89	...	X
Tredia							
1983-88	X
Van							
1988-90	...	X
3000GT							
1991-99 2WD	X
1991-99 AWD	X ⁽⁴⁾	...	X
<p>(1) Press TCS OFF button near shift lever. The TCS OFF indicator light will illuminate on instrument cluster when system is disabled.</p> <p>(2) Press TCL switch located on left side of dash. The TCL OFF indicator light will illuminate on instrument cluster when system is disabled.</p> <p>(3) Traction control cannot be disabled.</p> <p>(4) Cannot be shifted to 2WD.</p> <p>(5) Shift transfer case lever to 2H position.</p> <p>(6) Move switch located on right of steering column to 2WD. Ensure 4WD indicator light is off. Ensure center differential lock is off.</p>							

NISSAN

NISSAN

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Altima							
1993-2003	X
Axxess							
1990 2WD	X
1990 AWD	X ⁽¹⁾	...	X
Frontier							
1997-2003 2WD	...	X
1997-2003 4WD	...	X	X ⁽²⁾
Maxima							
1980-84	...	X
1985-98	X
1999-2003	X	X ⁽³⁾	...
Murano							
2003 2WD	X

2003 AWD	X ⁽¹⁾	...	X
Pathfinder							
1986-2003 2WD	...	X
2001-03 All Mode 4WD	...	X	X ⁽⁴⁾
1986-2003 w/o All Mode 4WD	...	X	X ⁽²⁾
Pickup							
1980-96 2WD	...	X
1980-96 4WD	...	X	X ⁽²⁾
Pulsar NX							
1983-94	X
Quest							
1993-2002	X
Sentra							
1982-2003	X
Sentra Wagon							
1988-2002 2WD	X
1988-90 AWD	X ⁽¹⁾	...	X
Stanza							
1985-92	X
Stanza Wagon							
1985-88 2WD	X
1985-88 AWD	X ⁽¹⁾	...	X
Van							
1988-90	...	X
Xterra							
2000-03 2WD	...	X
2000-03 4WD	...	X	X ⁽²⁾
200SX							
1980-88	...	X
1995-98	X
210, 510 & 810							
1980-82	...	X
310							
1980-82	X
240SX							
1989-98	...	X

1981-92	X
Trofeo							
1987-92	X
<p>(1) Press TRAC CTRL button located on the instrument panel. ETS OFF indicator light will illuminate when system is disabled.</p> <p>(2) Press ETS button located on center console. The TRAC OFF indicator light will illuminate when system is disabled.</p> <p>(3) Press traction control button located on center console. The TRAC OFF indicator light will illuminate when system is disabled.</p> <p>(4) Press TRACTION CONTROL button located on the center console. The light on the button will go off when the system is disabled.</p> <p>(5) Cannot be shifted to 2WD.</p> <p>(6) Press button on instrument panel to select 2HI position. Indicator light will illuminate when position is active.</p> <p>(7) Press T/C button located to right of steering wheel. The TRACTION OFF indicator light will illuminate when system is disabled.</p> <p>(8) On Elite models, button is in front door trim panel. On all other models, button is on instrument panel or center console. The TRAC OFF light will illuminate when system is disabled.</p>							

PEUGEOT

PEUGEOT

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
405							
1989-92	X
504							
1980-83	...	X
505							
1980-91	...	X
604							
1982-84	...	X

PLYMOUTH

PLYMOUTH

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Acclaim							
1989-95	X

Arrow							
1980	...	X
Breeze							
1996-2000	X
Caravelle							
1984-88 FWD	X
1980-89 RWD	...	X
Champ							
1980-82	X
Colt							
1983-94	X
Colt Wagon & Colt Vista							
1984-94 2WD	X
1984-94 AWD	X ⁽¹⁾	...	X
Conquest							
1984-86	...	X
Duster							
1992-94	X
Gran Fury							
1980-89	...	X
Horizon							
1980-90	X
Laser							
1990-94 2WD	X
1990-94 AWD	X ⁽¹⁾	...	X
Neon							
1995-99	X
2000-02	X	X ⁽²⁾	...
Prowler							
1997-2002	...	X
Reliant							
1981-89	X
Sapporo							
1980-83	...	X
Scamp							
1982-84	X
Sundance							
1987-94	X

TC3 & Turismo

1980-87	X
Volare							
1980	...	X
Voyager							
1984-96 FWD	X
1997-2003 FWD	X	X ⁽²⁾	...
1991-96 AWD	X ⁽¹⁾	...	X
1997-2000 AWD	X ⁽¹⁾	X	X

(1) System cannot be shifted to 2WD.

(2) Press switch located on instrument panel to disable system. The TRAC OFF indicator light in message center or instrument panel will illuminate when system is disabled.

PONTIAC**PONTIAC**

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Aztek							
2001-03 2WD	X	X ⁽¹⁾	...
2001-03 AWD	X ⁽²⁾	...	X
Bonneville							
1980-86	...	X
1987-91	X
1992-2003	X	X ⁽³⁾	...
Catalina							
1980-81	...	X
Fiero							
1984-88	...	X
Firebird							
1980-93	...	X
1994	...	X	X ⁽⁴⁾	...
1995-98	...	X	X ⁽³⁾	...
1999-2002	...	X	X ⁽⁶⁾	...
Grand Am							
1980	...	X

1985-94	X
1995-1998	X	X ⁽³⁾	...
1999-2003	X	X ⁽⁵⁾	...
Grand Prix							
1980-87	...	X
1988-95	X
1996-2003	X	X ⁽⁶⁾	...
LeMans							
1980-81	...	X
1988-93	X
Montana							
1999-2003	X	X ⁽⁷⁾	...
Parisienne							
1980-86	...	X
Phoenix							
1980-85	X
Safari							
1980-89	...	X
Sunbird							
1980	...	X
1984-94	X
Sunfire							
1995-2000	X	X ⁽³⁾	...
2001-03	X	X ⁽⁵⁾	...
Trans Am							
1982-92	...	X
Trans Sport							
1990-1994	X
1995	X	X ⁽⁷⁾	...
1996	X
1997-98	X	X ⁽⁷⁾	...
Vibe							
2003 2WD	X
2003 AWD	X ⁽²⁾	...	X
1000							
1980-87	...	X
2000							

2003	...	X	X ⁽²⁾	...
Cayenne							
2003	X ⁽³⁾	...	X
924							
1980-88	...	X
944							
1983-91	...	X
928							
1980-95	...	X
968							
1992-95	...	X
<p>(1) Push traction control switch on left side of dash to disable system. Indicator light will illuminate when system is disabled.</p> <p>(2) Push PSM-OFF switch located left of cupholder. Indicator light will illuminate when system is disabled.</p> <p>(3) Cannot be shifted to 2WD.</p>							

RENAULT

RENAULT

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Alliance							
1983-87	X
Encore							
1983-87	X
Fuego							
1982-86	X
GTA							
1987	X
LeCar							
1980-83	X
Sportwagon							
1984-86	X
18i							
1981-83	X

SAAB

SAAB

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
9-3 series							
1999-2000	X
2001-03	X	X ⁽¹⁾	...
9-5							
1999-2003	X	X ⁽¹⁾	...
99							
1980	X
900							
1980-93	X
1994-98	X	X ⁽¹⁾	...
9000							
1986-91	X
1992-94	X	X ⁽²⁾	...	X
1995-97	X	X ⁽¹⁾ 1	...
<p>(1) Push TCS switch located on dash/console to disable system. TCS OFF/sliding car OFF indicator light on instrument panel will illuminate when system is disabled.</p> <p>(2) Traction control cannot be disabled.</p>							

SATURN

SATURN

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Ion							
2003	X
L-Series							
2000-03	X	X ⁽¹⁾	...
S-Series							
1993-2002	X	X ⁽¹⁾	...
Vue							
2002-03 AWD	X ⁽²⁾	...	X
2002-03 2WD	X	X ⁽¹⁾	...
<p>(1) Press TCS or TRAC switch located on dash to disable system. Switch will no longer be illuminated when system is disabled.</p> <p>(2) Cannot be shifted to 2WD.</p>							

SUBARU

SUBARU

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Baja							
2003	X ⁽²⁾	...	X
Brat							
1980-87 2WD	X
1980-87 4WD	X ⁽²⁾	X
Forester							
1998-2003	X ⁽²⁾	...	X
Impreza							
1993-2003 AWD	X ⁽²⁾	...	X
1993-98 2WD	X
Justy							
1987-94 AWD	X ⁽²⁾	...	X
1987-94 2WD	X
Legacy							
1990-94 2WD	X
1995-98 2WD	X
1990-94 4WD	X ⁽²⁾	...	X
1995-97 4WD	X ⁽²⁾	X ⁽³⁾	X
1998-2003 4WD	X ⁽²⁾	...	X
Loyale							
1990-94 2WD	X
1990-94 4WD	X ⁽²⁾	...	X
Outback							
1997-2003	X ⁽²⁾	...	X
SVX							
1992-97	X ⁽²⁾	...	X
XT							
1986-91 2WD	X
1986-91 4WD	X	X ⁽¹⁾

(1) Move drive range selector to FWD position to disengage rear axle.

(2) Cannot be shifted to 2WD.

(3) Push TC OFF switch located on dash. Indicator light will illuminate when system is disabled.

SUZUKI

SUZUKI

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
Aerio							
2002-2003 2WD	X
2003 4WD	X ⁽²⁾	...	X
Esteem							
1995-2002	X
Grand Vitara							
1999-2003	...	X	X ⁽¹⁾
Samurai							
1986-95 2WD	...	X
1986-95 4WD	...	X	X ⁽¹⁾
Sidekick							
1989-98 2WD	...	X
1989-98 4WD	...	X	X ⁽¹⁾
Swift							
1989-2001	X
Vitara							
1999-2003 2WD	...	X
1999-2003 4WD	...	X	X ⁽¹⁾
XL-7							
2001-03	...	X	X ⁽¹⁾
X90							
1996-98 2WD	...	X
1996-98 4WD	...	X	X ⁽¹⁾

(1) Shift transfer case lever to 2H position.

(2) Cannot be shifted to 2WD.

1980-99	X
Tercel Wagon							
1982-88 A/T 4WD	X	...	X ⁽⁸⁾
1982-88 M/T 4WD	X	...	X ⁽⁶⁾
Tundra							
2000-03 2WD	...	X
2000-03 4WD	...	X	X ⁽⁶⁾ , ⁽⁹⁾
T100							
1993-97 2WD	...	X
1993-97 4WD	...	X	X ⁽⁶⁾
Van							
1984-89	...	X
4Runner							
1984-2000 2WD	...	X
2001-03 2WD	...	X	X ⁽¹⁾	...
1984-95 4WD	...	X	X ⁽⁶⁾
1996-2000 4WD	...	X	X ⁽⁶⁾⁽⁷⁾
2001-03 4WD	...	X	X ⁽⁷⁾	X ⁽¹⁾	...

- (1) Press TRAC OFF/VSC OFF button on dash to disable system. The TRAC OFF or VSC light will illuminate when system is disabled.
- (2) TRAC OFF switch is down and left from the steering column. Indicator light will illuminate when system is disabled.
- (3) TRAC OFF switch is above the gear shifter. Indicator light will illuminate when system is disabled.
- (4) Traction control system cannot be disabled.
- (5) Cannot be shifted to 2WD.
- (6) Shift transfer case lever to H2/FWD position. Ensure 4WD indicator is off.
- (7) Shift transfer case lever to H position, then depress the 4WD switch. Ensure vehicle is in 2WD.
- (8) Press button on A/T shift selector to FWD mode.
- (9) Press the 2WD/4HI switch and ensure that the 4HI and 4LO indicator lights are off.

TRIUMPH

TRIUMPH

--	--	--	--	--	--	--	--

1994-2003	X	X ⁽¹⁾	...
New Beetle							
1998-2003	X	X ⁽¹⁾	...
Passat							
1990-92	X
1993-2003	X	X ⁽¹⁾	...
Passat Sedan W8/Passat Wagon W8							
2003	X	X ⁽¹⁾	X
Quantum							
1982-88	X
Quantum GL Syncro Wagon							
1986-1988	X ⁽³⁾	...	X
Quattro Syncro							
1987-88	X	X ⁽³⁾	...	X
Rabbit							
1980-84	X
Rabbit Pickup							
1980-84	X
Scirocco							
1980-89	X
Vanagon							
1980-91	X
Vanagon Syncro							
1987-91	X ⁽³⁾	...	X
(1) Press ASR switch. The ASR indicator light will illuminate when system is disabled.							
(2) ESP switch is to the right of the steering column. Indicator light will illuminate when system is disabled.							
(3) Cannot be shifted to 2WD.							
(4) Information from manufacturer is not available at time of publication.							

VOLVO

VOLVO

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
240							
1980-93	...	X

260							
1980-82	...	X
740							
1985-91	...	X
760							
1983-90	...	X
780							
1986-90	...	X
850							
1992-97	X
940							
1991-95	...	X
960							
1992-97	...	X
Coupe							
1990-91	...	X
C70 & S70							
1998-2003	X	X ⁽¹⁾	...
Cross Country							
2003	X ⁽⁴⁾	X ⁽²⁾	X
S40 & V40							
2000-03	X	X ⁽³⁾	...
S60							
2001-03	X	X ⁽²⁾	...
S80							
1999-2003	X	X ⁽²⁾	...
S90							
1997-98	X
V70							
1998-2000 AWD	X ⁽⁴⁾	X ⁽¹⁾	X
1998-2000 2WD	X	X ⁽¹⁾	...
2001-03 AWD	X ⁽⁴⁾	X ⁽³⁾	X
2001-03 2WD	X	X ⁽²⁾	...
V90							
1997-98	X
XC90							
2003 AWD			X

					X ⁽⁴⁾	X ⁽²⁾	
2003 2WD	X	X ⁽²⁾	...

- (1) Press TRACS or STC switch located on dash. Indicator light will illuminate when system is disabled.
- (2) Press STC/DSTC switch on center console and hold down for more than half a second. The light in the switch will go off when system is disabled.
- (3) Press STC, DSA or DSTC switch located on dash to disable system. Indicator light will illuminate when system is disabled. On models equipped with winter/wet driving mode, depress the "W" switch on center console. The LED on switch will turn off when winter/wet driving mode is disengaged.
- (4) Cannot be shifted to 2WD.

YUGO

YUGO

Application	FWD	RWD	Part Time 4WD	Full Time 4WD	AWD	TCS	Do Not Test
GV & GVL							
1985-91	X